



## I. Basic Shortcuts / FN Combination Functions 1

| Key Combination | Function Description | Key Combination | Function Description |
|-----------------|----------------------|-----------------|----------------------|
| Fn + Esc        | Type •               | Shift + Esc     | Type ~               |
| Fn + <          | Pause                | Fn + >          | Print                |
| Fn + /          | Ins                  | Fn + ↑          | PgUp                 |
| Fn + ←          | Home                 | Fn + ↓          | PgDn                 |
| Fn + →          | End                  | Fn + Shift_R    | Del                  |
| Fn + 1          | F1                   | Fn + 2          | F2                   |
| Fn + 3          | F3                   | Fn + 4          | F4                   |
| Fn + 5          | F5                   | Fn + 6          | F6                   |
| Fn + 7          | F7                   | Fn + 8          | F8                   |
| Fn + 9          | F9                   | Fn + 0          | F10                  |
| Fn + -          | F11                  | Fn + +          | F12                  |

## II. Multimedia Control

| Key Combination | Function Description |
|-----------------|----------------------|
| Fn + Z          | Previous Track       |
| Fn + X          | Next Track           |
| Fn + C          | Play / Pause         |
| Fn + V          | Stop                 |
| Fn + B          | Mute                 |
| Fn + N          | Volume Down          |
| Fn + M          | Volume Up            |

## III. System Functions

| Key Combination        | Function Description                                                                              |
|------------------------|---------------------------------------------------------------------------------------------------|
| Fn + Win               | Lock / Unlock Win key. White LED lights up when locked.                                           |
| Fn + ALT_R (Right Alt) | Switch between Gaming Mode (custom actuation point) and Office Mode (2mm default actuation point) |

## IV. RGB Backlight Control / FN Combination Functions 2

| Key Combination | Function                 | Status Description                                                      |
|-----------------|--------------------------|-------------------------------------------------------------------------|
| Fn + Enter      | Lock F Keys              | Toggle between numeric and Fn functions, indicated by white LED         |
| Fn + U          | Lighting Mode Switch     | Cycle through all lighting effects                                      |
| Fn + Y          | Color Switch             | Change colors for adjustable lighting effects                           |
| Fn + T          | Turn Off / Turn On Light | Master LED switch with power-off memory function                        |
| Fn + F          | Brightness Down          | 10 adjustable levels, maximum brightness by default                     |
| Fn + G          | Brightness Up            | 10 adjustable levels, maximum brightness by default                     |
| Fn + H          | Speed Down               | 10 adjustable levels, 6th level by default                              |
| Fn + J          | Speed Up                 | 10 adjustable levels, 6th level by default                              |
| Fn + Tab        | Restore Defaults         | Press and hold for 5 seconds; red LED flashes 3 times to complete reset |

## V. Special Gaming Functions

| Key Combination                                                                                                                                                                                                                                                                                      | Function Name          | Description                                                                             |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|-----------------------------------------------------------------------------------------|
| Fn + Q (Configure via driver first)                                                                                                                                                                                                                                                                  | Double Keystroke (DKS) | Output A/D when pressed and D/A when released, ideal for quick stops in Counter-Strike  |
| Fn + E (Configure via driver first)                                                                                                                                                                                                                                                                  | Dual-Key SOCD          | Last-input priority, suitable for strafing and quick stops in Counter-Strike / Valorant |
| Double Keystroke (DKS) enables faster single-key quick stops for Counter-Strike. Dual-key Last-input Priority (SOCD) works for dual-key quick stops in Counter-Strike and strafing in Valorant. Enable and configure functions in the driver first, then turn them on or off with the shortcut keys. |                        |                                                                                         |