

61Key Module Gaming keyboard Operating Instructions

Features Define Function Definition

When powered on via USB connection, it cycles through 18 backlight effects. Hardware does not support recording, while recording is supported via the driver.

FN Composite Function	Shortcut Key		Shortcut Key
	Fn1+ Esc= •		Fn1+shift_L/shift_R+ESC=~
	Fn1+P=Print		Fn1+[=Scroll
	Fn1+]=Pause		Fn1+L=Insert
	Fn1+; : =Home		Fn1+' " =Page Up
	Fn1+<=Delete		Fn1+>=End
	Fn1+=Page Down		
	Fn1+1=F1		Fn1+2=F2
	Fn1+3=F3		Fn1+4=F4
	Fn1+5=F5		Fn1+6=F6
	Fn1+7=F7		Fn1+8=F8
	Fn1+9=F9		Fn1+0=F10
	Fn1+-=F11		Fn1++=F12
	Fn1+W= ↑		Fn1+S= ↓
	Fn1+A=←		Fn1+D=→
	Fn1+Z=Previous Track		Fn1+X=Next Track
	Fn1+C= Play/Pause		Fn1+V= Stop
	Fn1+B=Mute		Fn1+N=Volume-
	Fn1+M=Volume+		
	Shortcut Key	Function Definition	Status Description
	Fn1+WIN	Win Lock	After locking the "Win" key, the key will be non-functional (press it again to unlock). By default, it is not locked. When locked, the Win key indicator stays on, and you can cycle to switch it on or off.
	Fn1+SHIFT_R	Lock: WASD	By default, it uses WASD keys. After locking, the WASD keys switch to the direction keys (Up, Left, Down, Right) and light up white. The lock status can be toggled on and off by cycling through the switch.
	Fn1+Enter	Lock F Keys	By default, the keys function as 1 to +; after locking, they switch to F1 to F12 functions. When switching, the CAPS and WIN indicator lights flash 3 times for a prompt, and you can cycle to toggle the function on or off.
	Fn2+T	Turn Off the Light / Turn On the Light	Turn On and Turn Off the LED Lights of the Entire Keyboard
	FN2+Y	Color Switching	Color switching under the color-adjustable lighting effect

	FN2+U	Lighting Effect Switching	Cycle through all lighting effects
	Fn2+F	Light Brightness -	10-level adjustment, default to maximum
	Fn2+G	Light Brightness +	10-level adjustment, default to maximum
	Fn2+H	Light Speed -	10-level adjustment, default to Level 6
	Fn2+J	Light Speed +	10-level adjustment, default to Level 6
	FN2+ESC	Restore Default Settings	After pressing and holding for 5 seconds, all lights flash red 3 times and then reset; the light effects and function settings will all be restored to their default states.
Special Function	Fn1+Q	DKS	For keys A and D: when pressed, they output A and D respectively; when released, they output D and A respectively
	Fn1+E	SOCD	Press A first and then D: D is active; press D first and then A: A is active
	DKS: Single-key stop is faster, suitable for single-key stopping in CS. In this mode, the A and D keys light up red.		
	SOCD: Suitable for double-key stopping in CS and strafing in Valorant. In this mode, the A and D keys light up green.		
	When both functions are enabled, the A and D keys light up yellow.		